

Floor Graphics - Prep and Install Sheet

SURFACE PREPARATION:

Before you apply your floor graphics to a surface it is important you check the surface is absolutely dry, clean and in reasonable good condition ready for the application.

APPLICATION:

Your floor graphic must be applied in dry weather to a dry surface at temperatures above 10°C . The weather should remain dry for minimum 24h after application to ensure adhesion build-up on the surface.

Heat helps the adhesive to flow to the rough surface to create a better bond. Do not attempt to apply graphics late in the day when the temperature is expected to cool down.

The rougher the surface the less contact the adhesive will have and the less chance your graphic has for success.

To clean the surface, use a brush or a stiff bristle broom to remove dirt and dust, sand and gravel or other loose contaminants. Do not use water or cleaners which will cause the surface to become wet.

Once aligned, pull back 5cm of the liner to expose the adhesive to align and start the application. Remove 20cm of liner at a time and using a firm squeegee, short bristle brush or semi-hard roller with firm pressure, forcing the adhesive down into the surface. Make sure to eliminate air bubbles.

Bridge graphics over seams if needed but do not force the graphic down into the seam.

Once complete go back over all edges with firm pressure to make sure they are all in full contact to the surface.



Floor Graphic



Squeegee.